
定位销固定座

内螺纹型/外螺纹型/关节安装型 夹具用



型号			р	最小单位1		М	
代码		D _{g6}		L	F	外螺纹型	内螺纹型
	16	-0.006 -0.017	8	30		6 8 10	8 10
内螺纹型 外螺纹型 YKU01 YKU21 YKU02 YKU22	20		8 10 12	Ø70.000	F 05		10 14
	25	-0.007 -0.020	10 12 16	70~220	5~25	8 10	40 44 40
	30		12 16				10 14 18
			EXP				

型号			100		N				
代码	D	g6	TAIL	L	F	W	S	IN	
See the See the see	16	-0.006 -0.017	0 8					8 10	
关节安装型 YKU41 YKU42	20	A	8 10 12	70~220	5~25	16~40	10~30	10 12	
	25	-0.007 -0.020	10 12 16					12	
	30		12 16					12	





■ 内螺纹型								
型-	号	В	最小!	单位1	M			
代码	Dg6	P	L	F	内螺纹型			
KKUO	16	8	70=220	5~25	8 10			
YKU02	0	8 🕕 12	10-220	3~20	ID 14			
(1(110.4		D40 1	400	E40	1440			

YKU01-D20-P10-L100-F10-	- M10

○ 天节安装型									
型号		В	- 4		NI				
代码	Dg6	F	(L)	F	W	S	IN		
KU4	16	8	70-320	0-75	16-00	10-30	8 10		
YKU42	0	8 110 12	102220	3-20	10-40	10230	D 12		
YKU41-D20-P10-L100-F10-W20-S10-N10									



型号





内螺纹型

8 10 HC() TC() 525 (D) 14 (RD() NC()

最小单位1 L F

YKU01-D20-P10-L100-F10-M10-RD30



A6

定位销 夹具用衬套



可选加工代码

